



# FITTING INSTRUCTIONS

Part Number: 3500700

Product Anti-reflection tape kit

Description:

Suited to Any vehicle where sunlight or headlight reflection off bulbar top frame is a concern  
vehicle/s:

## WARNING

### NOTE THE FOLLOWING:

- ◆ This product must be installed exactly as per these instructions using only the hardware supplied.
- ◆ In the event of a damaged component, contact your nearest authorised ARB stockist.
- ◆ It is recommended that this product is only installed by trained personnel
- ◆ These instructions are correct as at the publication date. ARB Corporation Ltd. cannot be held responsible for the impact of any changes subsequently made by the vehicle manufacturer
- ◆ Work safely at all times

## ARB 4x4 ACCESSORIES

Corporate Head Office

42-44 Garden St  
Kilsyth, Victoria  
AUSTRALIA 3137

Tel: +61 (3) 9761 6622  
Fax: +61 (3) 9761 6807

Australian enquiries  
North & South American enquiries  
Other international enquiries

sales@arb.com.au  
sales@arbusa.com  
exports@arb.com.au

### FITTING REQUIREMENTS

#### REQUIRED TOOLS FOR FITMENT OF PRODUCT:

Scissors	
----------	--

**NOTE: 'WARNING' notes in the fitting procedure relate to OHS situations, where to avoid a potentially hazardous situation it is suggested that protective safety gear be worn or a safe work procedure be employed. If these notes and warnings are not heeded, injury may result.**

Kit Contains 1m of anti-reflection tape.

## Fitment: Read all steps before starting

1. Identify areas which reflect either sunlight or headlights back towards the driver.



To check for headlight reflection, check both high and low beam. The above picture shows high beams reflecting off the on the top outer frames of the bullbar when viewed from the driver's seat.

2. Measure length of tape required to mask the area



3. Cut tape to length and round corners as shown.



4. Use provided alcohol wipe to thoroughly clean the area to be covered.



5. Partly peel off one end of the tape backing. Hold the whole length of tape in the desired position and stick down the one exposed end.
6. While keeping the tape in the desired position, pull the backing out from underneath. If any wrinkles or bubbles form, pull tape back until the wrinkle and re apply.



7. Working from the centre out, stick down all of the tape.



8. Repeat process where ever additional tape is required