

Kingsley

STEPBOARDS®

Part No: 18R930

**RANGE ROVER Defender Dual Cab
1994 - Current
Component List**

Board Length: 1925mm MK6

End Caps: **Front** - 1 pair: Bullnose – Remove fins
Rear - 1 pair Bullnose – Remove fins

HARDWARE KIT CONTENTS

PART NO.	DESCRIPTION	QTY	PART NO.	DESCRIPTION	QTY
91Z001	M8 x 20mm BOLT	4	91Z019	M6 NYLOC NUT	6
91Z003	M8 x 14mm BOLT	28	91Z023	M8 FLAT WASHER	20
91Z017	M8 FLANGE NUT	16	91Z105	M8 LOCK WASHER	20
91Z018	M8 HEX NUT	20			

BRACKETS AND ANGLES

PART NO.	DESCRIPTION	QTY
9AW011	FRONT BRACKET	2
9AW012	CENTRE BRACKET	6
9AW013	REAR BRACKET	2

Check kit supplied is for the vehicle being fitted and is complete as listed.

TOOLS REQUIRED:

10 & 13mm Socket, Ratchet driver with extension, Ring & Set spanners

FITTING INSTRUCTIONS:

1. Start under vehicle on either side, identify 2 M8 bolts, 60mm apart under front edge of front doors – these bolts are in horizontal plane, running front to rear, immediately behind sill and near channel.
2. On these bolts, attach bracket (P/No. 9AW011) using M8 flange nuts from kit and discarding nuts and washers as fitted.
3. Move back along sill channel approximately 400mm and locate a 6mm bolt in channel (vertical). Remove nut and washer and attach centre bracket (P/No. 9AW012) using washer as fitted and M6 nyloc nut from kit.
4. Move back along sill channel a further 300mm and locate a 6mm bolt in channel (vertical). Remove nut and washer and fit another centre bracket as described above. Once again, move back a further 400mm and fit another centre bracket.
5. Move back to rear of rear door – locate chassis member that supports body. Attach bracket (P/No. 9AW013) on inside front face of this member, bolt up using M8x20mm bolt and flange nut from kit.
6. Assemble stepboards as follows:
 - Attach end-cap to one end of stepboard using M8x14mm bolts and flange nuts.
 - Slide into each channel of stepboard, 5 M8 hex nuts.
 - Attach other end-cap as described above.
7. Lift stepboard onto fitted brackets and attach with M8x14mm bolts, washers and lock washers from kit – picking up hex nuts in channels.
8. Ensure all nuts and bolts are tight before using stepboards and clean stepboards if necessary using **soapy water only**.

Your Stepboards are now ready for use

In accordance with our policy of total quality commitment and customer service, we invite you to contact us on our toll free hotline should you have any questions

Telephone: (02) 9792 2566 or Toll Free 1800 654 767

Kingsley Enterprises Pty Ltd 123 Eldridge Road Bankstown NSW 2200 Australia